




NEEM Project User Guide



Alpha MOS France
20, avenue Didier Daurat
31400 Toulouse – France
Tel: +33 5 62 47 53 80
info@alpha-mos.com

Alpha MOS America
7502 Connelley Drive, Suite 110
Hanover, MD 21075-1705 – USA
Tel: (410) 553-9736
amusa@alpha-mos.com

Alpha MOS China
Suite 705A, Xin Da Tower
#322 Xian Xia Road
Shanghai, P. R. China, 200336
Tel: 86 (0) 21 6208 1655
asia@alpha-mos.com

Alpha MOS Japan
Jowa Takanawa Bld. Minato-ku 8F
1-5-4 Takanawa
Tokyo 108-0074 - Japan
Tel: +81-3-5475-3291
japan@alpha-mos.com

Manual Reference NEEM-Systems_MBE (Request number to the production
dpt)

www.alpha-mos.com

RESTRICTED DISTRIBUTION

Distribution limited to :

Alpha MOS - All rights reserved

REVISION STATUS

INDEX	DATE (MM/YYYY)	AMENDED PAGES	NOTES
a	06/2010		Original release

All rights reserved

TABLE OF CONTENTS


1. USE AND FUNCTIONALITIES	9
2. INSTALLATION PROCEDURE	10
2.1 Fluid connection	10
2.2 Power connection	10
2.3 I2C Connection.....	11
2.4 I2C protocol	11
2.4.1 Set Chamber Temperature and pump voltage.....	11
2.4.2 Reading status, Temperature of chamber, voltage of pump and hygrometry	12
2.4.3 Writing heater tension	12
2.4.4 Reading sensors resistance	13
2.4.5 Example of information in the I2C bus	14
3. SPECIFICATIONS	16
4. APPENDIX.....	17
4.1 Appendix: LEDS code.....	17
4.1.1 LEDS designation.....	17
4.1.2 LED Colours and blinking code	17

SAFETY INFORMATION

This Neem Module is designed for integration within a flying system. It doesn't have any electrical nor thermal cover protection in order to reduce the weight.



- **Avoid touching the module when running; some parts could be hot.**
- **Avoid any contact with metallic or conductive part in order to prevent short cut**
- **Avoid touching the mechanically rotating part of the micro-pump**



Hot surfaces

rotating part



Warning: Do not use silicon (seal , grease, cleaning...) near the sensors.

This will poison the sensors.

DECLARATION OF CONFORMITY

This module is a prototype, no declaration of conformity is required

Alpha MOS - All rights reserved

COPYRIGHT

All copyright are reserved to Alpha MOS

Alpha MOS - All rights reserved

WARRANTY

The Neem Module is under warranty for one year starting from delivery, covering parts and labor at Alpha MOS factory (20 av Didier Daurat 31 400 Toulouse France).

Sensors are not under warranty.

Alpha MOS - All rights reserved




1. USE AND FUNCTIONALITIES

NEEM module is a small electronic nose dedicated to small flying aircrafts.

It will analyze gas thanks to 3 Metal Oxide Sensors :

- **S1** : P55/25 sensor dedicated to smoke detection (containing CO)
- **S2** : P30/1 sensor for COV, solvent, ethanol detection
- **S3** : P10/9 sensor for hydrogen detection




In order to obtain reproducible analysis conditions the gas flow is regulated by a pump and thermostated by a micro furnace. Hygrometry is also measured within the air flow.



2. INSTALLATION PROCEDURE


- *Carefully unpack the electronic nose*

2.1 Fluid connection



Connect tubing to the gas inlet M5 thread let available

2.2 Power connection




Connect Red wire to continuous Plus (9 to 18 Volts)

Connect Neutral to black wire



2.3 I2C Connection



Connect Black Wire : Mass

Connect Green wire : SDA (Serial Data line)

Connect Yellow wire : SCL (Serial Clock line)

2.4 I2C protocol

2.4.1 Set chamber temperature and pump voltage

When starting the module, all temperature values are set at 0 °C and pump voltage at 0 V.

Never apply less than 4V to the pump if chamber setpoint is applied. Without an airflow inside the system, thermal regulation is impossible. Anyway, the temperature of the furnace is limited to 130°C.

Writing T°C Chamber and pump Voltage Setpoint									
master bus									
slave bus									
		Adress			T°C setpoint		Pump voltage setpoint		
Module One	Start	0x52	Writing	Ack	8 bits	Ack	8 bits	Ack	Stop
					T°C *2		Voltage*20		
Nominal Value					80 (40°C)		100 (5V)		
					Don't applied T°C setpoint without applied a mimium of 4Volt to the pump				



NEEM MODULE

2.4.2 Reading status, chamber temperature, pump voltage and hygrometry

Reading Status, T°C, Pump Voltage, % of hygrometry												
master bus												
slave bus												
	Adress			Status		Room Temperature		Pump voltage		Hygrometry		
Module One	Start	0x52	read	Ack	8 bits	ack	8 bits	ack		8 bits	ack	stop
				Status (see table)		T°C *2		Voltage*20		% of hygrometry		

Status definition

	Temperature status				pump status			
	bit1	bit2	bit3	bit4	bit5	bit6	bit7	bit8
status table	Not used	Not used	Not used	Not used				
Temperature OK					0	0		
Temperature no OK								
Outside +/- 0,5°C					0	1		
No loading or pump stopped							0	0
pump Ok							0	1
Too much pump current							1	0

2.4.3 Writing heater tension


When starting the module, all values are set at 0.


Be careful, never apply more than 2.4 Volts to sensor 1 (value 87), since sensor could be damaged.

Writing sensors tension												
master bus												
slave bus												
	Adress			Sensor1 Heater Tension		Sensor 2 Heater Tension		Sensor 3 Heater Tension				
Module Two	Start	0x57	Write	ack	0x06	ack	8 bits	ack	8 bits	ack	8 bits	ack stop
							0 to 5.3 volt		0 to 5.3 volt		0 to 5.3 volt	
							0 -> 0V		0 -> 0V		0 -> 0V	
							1 -> 0.9 V		1 -> 0.9 V		1 -> 0.9 V	
							255 -> 5.3 Volt		255 -> 5.3 Volt		255 -> 5.3 Volt	
							V=57.72*Value-50.95		V=57.72*Value-50.95		V=57.72*Value-50.95	
Nominal Value							86 (2.39 V)		244 (5.1V)		244 (5.1V)	
							Never exceed 2.4 V for sensor 1 (Value =87)					



2.4.5 Example of information in the I2C bus








3. SPECIFICATIONS

- Length: 120 mm – Width: 55 mm – Height: 60 mm
- Weight: 185 g
- Power supply: 9V to 18V continuous
- Max Amperage: 1.8 Amps
- Power consumption (Pump voltage: 6V, Chamber T°: 40°C, outside T°: 25°C , input voltage: 12V) : 4 Watts (max current during test 0.45 Amps)
- I2C voltage: 5V
- Air flow through the system : the air flow depends on tension applied. It is adjustable between 0.25 and 0.75 L per minute



Tests have been performed to check sensors activity.

The sensors react correctly with the following gases:

- H₂
- Smoke (coming from cigarette)
- Butane
- Ethanol

The system has run for four days without any trouble, at 60 °C with the pump at 6 V.



4. APPENDIX

4.1 Appendix: LEDS code


4.1.1 LEDS designation

LED 1: Power LED

LED 2: I2C LED

LED 3: Motor LED

LED 4: T°C LED



4.1.2 LED Colours and blinking code

LED 1: POWER LED : Green when power is "ON"

LED 2: I2C LED : Green when communication on I2C

LED 3: MOTOR LED : Red blinking if motor not present or not started
Red permanent if too much current required
Off if normal

LED 4: heater LED : Off if T°C comprised between +/- 0.5°C around chamber T°C setpoint
Red blinking if outside